

Swing Clear Rural Model #442

Installation Guide

- Attach spade plate to base pipe (flattened on one end) with two hex bolts provided, larger gold bolt in top hole of spade.
- Loosen set bolt (orange) near top of base pipe.
- Drive base pipe into road edge approximately 40" back from road surface or final position desired for mail box. To do this use a block of wood (or piece of 2 x 4) resting on top of base and hit with a heavy hammer or maul to drive base leaving orange painted top 6-10 inches above the ground. Make sure, spades on base are positioned parallel to roadway. **IMPORTANT:** Always check for underground utilities before installation.
- Slide bent upright into base and lightly turn in set bolt to hold against upright pipe, with wrench. Adjust bent top to face directly toward roadway and tighten set bolt more securely.
- Assemble your current mailbox (or new one) onto boom arm with 2 1/2" carriage bolts provided (some drilling of the mail box base board may be required).
- Slide swivel joint end of boom onto bent upright.
- Adjust height above road surface and bottom of mail box to approximately 42" by loosening set bolt at top of the base pipe and retightening when properly positioned.
- **NOTE:** Sometimes with drop-off ditches, if base pipe is in a much lower position an extended upright pipe may be needed. Contact your dealer or www.swingclear.com

